

---

---

# Innovatint version 3 Standard characterization mixtures Lab



## Table of contents

1.	Overview	2
2.	Clear base characterization	3
2.1	Bootstrap	3
2.2	Colorants	3
2.3	White bases	4
2.4	Clear bases	5
2.5	Colored bases	5
3.	White base characterization	7
3.1	Bootstrap	7
3.2	Colorants	7
3.3	White bases	8
3.4	Clear bases	9
3.5	Colored bases	9



## 1. Overview

All mixtures are to be made in volume.

Always use the exact density on the colorant can to make the mixtures in the lab.

All mixtures to be made on 250 microns.



## 2. Clear base characterization

### 2.1 Bootstrap

The bootstrap is a set of mixtures to characterize your system white, system black and the transparent base. These 3 components will be used in the characterization of all other colorants.

The mixtures are determined based on the maximum colorant addition.

	<i>Mix Ratio</i>	<i>Part (%)</i>	
		<i>Black</i>	<i>White</i>
Mixture 1	Mass tone black colorant	100	0
Mixture 2	5/95	5	95
Mixture 3	15/85	15	85
Mixture 4	40/60	40	60
Mixture 5	80/20	80	20
Mixture 6	100/0	100	0
Mixture 7	40/0	40	0
Mixture 8	15/0	15	0
Mixture 9	Mass tone white colorant	0	100
Mixture 10	Mass tone clear base	0	0

Example where the maximum colorant addition is 7% and the base has a fill level of 93%.

	<i>Mix Ratio</i>	<i>Part (ml)</i>		
		<i>Black</i>	<i>White</i>	<i>Clear base</i>
Mixture 1	Mass tone black colorant	70	0	930
Mixture 2	5/95	3,5	66.5	930
Mixture 3	15/85	10,5	59,5	930
Mixture 4	40/60	28	42	930
Mixture 5	80/20	56	14	930
Mixture 6	100/0	70	0	930
Mixture 7	40/0	28	0	930
Mixture 8	15/0	10,5	0	930
Mixture 9	Mass tone white colorant	0	70	930
Mixture 10	Mass tone clear base	0	0	930

All mixtures have to be activated.



## INNOVATINT STANDARD CHARACTERIZATION MIXTURES LAB

### 2.2 Colorants

The mixtures are determined based on the fill level of the base and maximum colorant addition. For blue and green colorant use a double amount of black -> 98% colorant and 2% of black.

	<i>Mix Ratio</i>	<i>Part (%)</i>		
		<i>COL</i>	<i>Black</i>	<i>White</i>
Mixture 1	Mass tone	<i>100</i>	<i>0</i>	<i>0</i>
Mixture 2	5/95 %	<i>5</i>	<i>0</i>	<i>95</i>
Mixture 3	15/85 %	<i>15</i>	<i>0</i>	<i>85</i>
Mixture 4	40/60 %	<i>40</i>	<i>0</i>	<i>60</i>
Mixture 5	80/20 %	<i>80</i>	<i>0</i>	<i>20</i>
Mixture 6	99/1 %	<i>99</i>	<i>1</i>	<i>0</i>

Example where the maximum colorant addition is 7% and the base has a fill level of 93%.

	<i>Mix Ratio</i>	<i>Part (ml)</i>			
		<i>COL</i>	<i>Black</i>	<i>White</i>	<i>Clear base</i>
Mixture 1	Mass tone	<i>70</i>	<i>0</i>	<i>0</i>	<i>930</i>
Mixture 2	5/95 %	<i>3,5</i>	<i>0</i>	<i>66,5</i>	<i>930</i>
Mixture 3	15/85 %	<i>10,5</i>	<i>0</i>	<i>59,5</i>	<i>930</i>
Mixture 4	40/60 %	<i>28</i>	<i>0</i>	<i>42</i>	<i>930</i>
Mixture 5	80/20 %	<i>56</i>	<i>0</i>	<i>14</i>	<i>930</i>
Mixture 6	99/1 %	<i>69,3</i>	<i>0,7</i>	<i>0</i>	<i>930</i>

### 2.3 White bases

Additional white bases can be characterized with the following mixtures. The mixtures are determined based on the maximum colorant addition.

	<i>Mix Ratio</i>	<i>Part (%)</i>
		<i>Black</i>
Mixture 1	Max. Col. Ad.	<i>100</i>
Mixture 2	Black Addition 40 %	<i>40</i>
Mixture 3	Black Addition 15 %	<i>15</i>
Mixture 4	Black Addition 10 %	<i>10</i>
Mixture 5	Black Addition 5 %	<i>5</i>
Mixture 6	Mass tone white base	<i>0</i>



## INNOVATINT STANDARD CHARACTERIZATION MIXTURES LAB

Example where the maximum colorant addition is 1,6% and the base has a fill level of 100%.

	<i>Mix Ratio</i>	<i>Part (ml)</i>	
		<i>Black</i>	<i>White base</i>
Mixture 1	Max. Col. Ad.	<i>16</i>	<i>1000</i>
Mixture 2	Black Addition 40 %	<i>6,4</i>	<i>1000</i>
Mixture 3	Black Addition 15 %	<i>2,4</i>	<i>1000</i>
Mixture 4	Black Addition 10 %	<i>1,6</i>	<i>1000</i>
Mixture 5	Black Addition 5 %	<i>0,8</i>	<i>1000</i>
Mixture 6	Mass tone white base	<i>0</i>	<i>1000</i>

### 2.4 Clear bases

Additional clear bases can be characterized with the following mixtures. The mixtures are determined based on the maximum colorant addition.

	<i>Mix Ratio</i>	<i>Part (%)</i>	
		<i>Black</i>	<i>White</i>
Mixture 1	Black Addition 100%	<i>100</i>	<i>0</i>
Mixture 2	Black Addition 40 %	<i>40</i>	<i>0</i>
Mixture 3	Black Addition 15 %	<i>15</i>	<i>0</i>
Mixture 4	White Addition 100%	<i>0</i>	<i>100</i>
Mixture 5	Mass tone clear base	<i>0</i>	<i>0</i>

Example where the maximum colorant addition is 7% and the base has a fill level of 93%.

	<i>Mix Ratio</i>	<i>Part (ml)</i>		
		<i>Black</i>	<i>White</i>	<i>Clear base</i>
Mixture 1	Black Addition 100%	<i>70</i>	<i>0</i>	<i>930</i>
Mixture 2	Black Addition 40 %	<i>28</i>	<i>0</i>	<i>930</i>
Mixture 3	Black Addition 15 %	<i>10,5</i>	<i>0</i>	<i>930</i>
Mixture 4	White Addition 100%	<i>0</i>	<i>70</i>	<i>930</i>
Mixture 5	Mass tone clear base	<i>0</i>	<i>0</i>	<i>930</i>



## INNOVATINT STANDARD CHARACTERIZATION MIXTURES LAB

### 2.5 Colored bases

Additional colored bases can be characterized with the following mixtures.

The mixtures are determined based on the maximum colorant addition.

	<i>Mix Ratio</i>	<i>Part (%)</i>	
		<i>White</i>	<i>Black</i>
Mixture 1	1/99 %	<i>1</i>	<i>0</i>
Mixture 2	15/85 %	<i>15</i>	<i>0</i>
Mixture 3	40/60 %	<i>40</i>	<i>0</i>
Mixture 4	80/20 %	<i>80</i>	<i>0</i>
Mixture 5	100/0 %	<i>100</i>	<i>0</i>
Mixture 6	98/2 %	<i>0</i>	<i>2</i>
Mixture 7	Mass tone colored base	<i>0</i>	<i>0</i>

Example where the maximum colorant addition is 7% and the base has a fill level of 93%.

	<i>Mix Ratio</i>	<i>Part (ml)</i>		
		<i>White</i>	<i>Black</i>	<i>Colored base</i>
Mixture 1	1/99 %	<i>0,7</i>	<i>0</i>	<i>930</i>
Mixture 2	15/85 %	<i>10,5</i>	<i>0</i>	<i>930</i>
Mixture 3	40/60 %	<i>28</i>	<i>0</i>	<i>930</i>
Mixture 4	80/20 %	<i>56</i>	<i>0</i>	<i>930</i>
Mixture 5	100/0 %	<i>70</i>	<i>0</i>	<i>930</i>
Mixture 6	98/2 %	<i>0</i>	<i>1,4</i>	<i>930</i>
Mixture 7	Mass tone colored base	<i>0</i>	<i>0</i>	<i>930</i>



### 3. White base characterization

#### 3.1 Bootstrap

The characterization of colorants in the white base requires also the use a clear base. The white base will be used as a replacement of the white colorant.

	<i>Mix Ratio</i>	<i>Part (%)</i>
		<i>Black</i>
Mixture 1	Pure white base	0
Mixture 2	5 %	5
Mixture 3	15 %	15
Mixture 4	40 %	40
Mixture 5	80 %	80
Mixture 6	Mass tone white base	100
Mixture 7	Mass tone clear base	100
Mixture 8	Pure clear base	0

Example where the colorant addition is 3% in the white base (base is 100%) and 7% in the transparent base (base is 93%).

	<i>Mix Ratio</i>	<i>Part (ml)</i>		
		<i>Black</i>	<i>White base</i>	<i>Clear base</i>
Mixture 1	Pure white base	0	1000	0
Mixture 2	5 %	1,5	1000	0
Mixture 3	15 %	4,5	1000	0
Mixture 4	40 %	12	1000	0
Mixture 5	80 %	24	1000	0
Mixture 6	Mass tone white base	30	1000	0
Mixture 7	Mass tone clear base	70	0	930
Mixture 8	Pure clear base	0	0	930

#### 3.2 Colorants

The mixtures are determined based on the fill level of the base and maximum colorant addition.





## INNOVATINT STANDARD CHARACTERIZATION MIXTURES LAB

	<i>Mix Ratio</i>	<i>Part (%)</i>
		<i>COL</i>
Mixture 1	Mass tone	<i>100</i>
Mixture 2	5 %	<i>5</i>
Mixture 3	15 %	<i>15</i>
Mixture 4	40 %	<i>40</i>
Mixture 5	80 %	<i>80</i>
Mixture 6	Mass tone clear base	<i>100</i>

Example where the colorant addition is 3% in the white base (base is 100%) and 7% in the transparent base (base is 93%).

	<i>Mix Ratio</i>	<i>Part (ml)</i>		
		<i>COL</i>	<i>White base</i>	<i>Clear base</i>
Mixture 1	Mass tone	<i>30</i>	<i>1000</i>	<i>0</i>
Mixture 2	5 %	<i>1,5</i>	<i>1000</i>	<i>0</i>
Mixture 3	15 %	<i>4,5</i>	<i>1000</i>	<i>0</i>
Mixture 4	40 %	<i>12</i>	<i>1000</i>	<i>0</i>
Mixture 5	80 %	<i>24</i>	<i>1000</i>	<i>0</i>
Mixture 6	Mass tone clear base	<i>70</i>	<i>0</i>	<i>930</i>

### 3.3 White bases

Additional white bases can be characterized with the following mixtures. The mixtures are determined based on the maximum colorant addition.

	<i>Mix Ratio</i>	<i>Part (%)</i>
		<i>Black</i>
Mixture 1	Max. Col. Ad.	<i>100</i>
Mixture 2	Black Addition 40 %	<i>40</i>
Mixture 3	Black Addition 15 %	<i>15</i>
Mixture 4	Black Addition 10 %	<i>10</i>
Mixture 5	Black Addition 5 %	<i>5</i>
Mixture 6	Mass tone white base	<i>0</i>



## INNOVATINT STANDARD CHARACTERIZATION MIXTURES LAB

Example where the maximum colorant addition is 1,6% and the base has a fill level of 100%.

	<i>Mix Ratio</i>	<i>Part (ml)</i>	
		<i>Black</i>	<i>White base</i>
Mixture 1	Max. Col. Ad.	<i>16</i>	<i>1000</i>
Mixture 2	Black Addition 40 %	<i>6,4</i>	<i>1000</i>
Mixture 3	Black Addition 15 %	<i>2,4</i>	<i>1000</i>
Mixture 4	Black Addition 10 %	<i>1,6</i>	<i>1000</i>
Mixture 5	Black Addition 5 %	<i>0,8</i>	<i>1000</i>
Mixture 6	Mass tone white base	<i>0</i>	<i>1000</i>

### 3.4 Clear bases

Additional clear bases can be characterized with the following mixtures. The mixtures are determined based on the maximum colorant addition.

	<i>Mix Ratio</i>	<i>Part (%)</i>	
		<i>Black</i>	<i>White base</i>
Mixture 1	Black Addition 100%	<i>100</i>	<i>0</i>
Mixture 2	Black Addition 40 %	<i>40</i>	<i>0</i>
Mixture 3	Black Addition 15 %	<i>15</i>	<i>0</i>
Mixture 4	Black Addition 10 %	<i>10</i>	<i>0</i>
Mixture 5	Black Addition 5 %	<i>5</i>	<i>0</i>
Mixture 6	White Addition 100%	<i>0</i>	<i>100</i>
Mixture 7	Mass tone clear base	<i>0</i>	<i>0</i>

Example where the maximum colorant addition is 7% and the base has a fill level of 93%.

	<i>Mix Ratio</i>	<i>Part (ml)</i>		
		<i>Black</i>	<i>White base</i>	<i>Clear base</i>
Mixture 1	Black Addition 100%	<i>70</i>	<i>0</i>	<i>930</i>
Mixture 2	Black Addition 40 %	<i>28</i>	<i>0</i>	<i>930</i>
Mixture 3	Black Addition 15 %	<i>10,5</i>	<i>0</i>	<i>930</i>
Mixture 4	Black Addition 10 %	<i>7</i>	<i>0</i>	<i>930</i>
Mixture 5	Black Addition 5 %	<i>0,7</i>	<i>0</i>	<i>930</i>
Mixture 6	White Addition 100%	<i>0</i>	<i>70</i>	<i>930</i>
Mixture 7	Mass tone clear base	<i>0</i>	<i>0</i>	<i>930</i>

### 3.5 Colored bases

Additional colored bases can be characterized with the following mixtures.



## INNOVATINT STANDARD CHARACTERIZATION MIXTURES LAB

The mixtures are determined based on the fill level of the base.

	<i>Mix Ratio</i>	<i>Part (%)</i>	
		<i>White base</i>	<i>Black</i>
Mixture 1	80/20 %	<i>80</i>	<i>0</i>
Mixture 2	60/40 %	<i>60</i>	<i>0</i>
Mixture 3	20/80 %	<i>20</i>	<i>0</i>
Mixture 4	98/0.2 %	<i>0</i>	<i>2</i>
Mixture 5	Mass tone colored base	<i>0</i>	<i>0</i>

Example where the base has a fill level of 100%.

	<i>Mix Ratio</i>	<i>Part (ml)</i>		
		<i>White base</i>	<i>Black</i>	<i>Colored base</i>
Mixture 1	80/20 %	<i>800</i>	<i>0</i>	<i>200</i>
Mixture 2	60/40 %	<i>600</i>	<i>0</i>	<i>400</i>
Mixture 3	20/80 %	<i>200</i>	<i>0</i>	<i>800</i>
Mixture 4	98/0.2 %	<i>0</i>	<i>2</i>	<i>1000</i>
Mixture 5	Mass tone colored base	<i>0</i>	<i>0</i>	<i>1000</i>